



	<b>POWER:</b> Turn the Document Camera on/off.		<b>LAMP:</b> Turn the lamp on/off.
	<b>AUTO TUNE:</b> Automatically adjust the image to have the best brightness and focusing performance.		<b>PREVIEW:</b> Display live images.
	<b>OPTIONS:</b> Select video compression method and the audio source. <a href="#">6.6 Options</a> is the reference of the selecting screen.		<b>BRIGHTNESS:</b> Manually adjust the brightness of the image.
	<b>MAIN:</b> Launch the main functions menu. Right click on this icon to show information about the Ladibug™.		<b>ZOOM:</b> Increase or decrease the image size.
	<b>Mask Mode:</b> Open the mask mode. Please refer to <a href="#">7.9 I would like to use the mask mode</a> .		<b>CAMERA SETTING:</b> Launch the Camera Setting window to adjust live images. <a href="#">6.5 CAMERA Settings</a> is the reference of the selecting screen.
	<b>FREEZE:</b> Freeze the live image.		<b>ANNOTATION:</b> Open the annotation tools. Please refer to <a href="#">6.4 Annotation</a> .
	<b>Spotlight Mode:</b> Open the emphasizing mode. Please refer to <a href="#">7.10 I would like to use the spotlight mode</a> .		<b>TIME LAPSE PHOTOGRAPHY:</b> Use the burst mode and adjust the interval of automatic image capturing. Please refer to <a href="#">7.4 I would like to capture images continuously</a> .
	<b>RECORD:</b> Record the current image.		<b>CAPTURE:</b> Image Capture.